

# Acrylic Canvas Cleaning Instructions

1. Eliminate dirt by gently brushing or vacuuming the fabric
2. Do Not use a pressure washer
3. Wash carefully without excessive scrubbing using a solution of water and neutral soap (at a temperature of no more than 30°C)
4. Do not use detergents, chlorine solutions or solvents
5. Rinse with abundant water and allow to dry naturally
6. Do not tumble dry
7. Ensure fabric is dry completely before storage
8. For best results, fabric should be re-proofed after washing and drying

## Kayospruce Cleaning Products:

- FAB006 - Fabsil Aerosol re-proofer
- FAB151 - Fabsil Gold 1 litre tin of re-proofer
- REN001 - Renovo Cleaner 500ml
- REN003 - Renovo Proofer 500ml
- CLN100 - Cover Care Kit

